





TECHNICAL CATALOGUE





3rd edition Jan.2024 Additional information This catalogue shows the product in the most standard configurations. Please contact Sales Dpt. for more detailed information or special request. **WARNING!** All specifications of this catalogue refer to the standard product at this date. Walvoil, oriented to a continuous improvement, reserves the right to discontinue, modify or revise the specifications, without notice.

WALVOIL IS NOT RESPONSIBLE FOR ANY DAMAGE CAUSED BY AN

INCORRECT USE OF THE PRODUCT.





Applications

Ideal for mini-excavators between 1 t and 2.5 t. Especially limited size and weight. It can be equipped with:

- 2 or 3 pumps circuit
- flow addition on PTO function
- second travel speed
- regenerating system on the arm
- flow addition on the boom
- flow addition on the bucket
- flow addition on the arm
- straight travel
- built in boom anti-drift
- various kinds of hydraulic and manual controls
- any number of customisations and set-ups

Suitable for applications including Mini-backhoe loaders, Skid-steer loaders, Mini skid loaders, Mini dumpers and Forestry machines.

Different kind of manual and hydraulic remote controls. Countless configurations and custom made solutions. Working sections have auxiliary valves and a broad range of interchangeable spools.













QUICK REFERENCE GUIDE

GENERAL SPECIFICATION	D9	DЗΜ	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Working sections number	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-12	1-10
CIRCUIT											
Parallel	•	•	•	•	•	•	•	•	•	•	•
Series	•	•	•	•	•	•	•		•	•	
Tandem	•	•	•	•	•	•		•	•		
Parallel circuit stroke (mm)	6	5	6	6	7	7	9,5	9,5	9,5	12	15
Series circuit stroke (mm)	6	5	6	6	5	7	6,5		6,5	8,5	
Float spool extra stroke (mm)	5	5	5	5,5	6	7	7	7	7	9,5	10
Spools pitch (mm)	31	38	35	40	46	46	56	56	64	75	91
RATED FLOW											
Max recommended flow rate (I/min)	35	55	45	80	100	150	180	250	250	380	700
Max recommended flow rate (GPM)	10	15	12	22	27	40	48	67	67	100	185
RATED PRESSURE											
Max working pressure (bar)*	315	350	350	350	315	350	350	250	350	350	350
Max working pressure (PSI)*	4500	5000	5000	5000	4500	5000	5000	4000	5000	5000	5000

NOTE (*): Intermittent pressure at max. 1 million cycles with specific internal testing.

OPTION CHART	D9	рзм	DVS10	D4	D6	D16	D12	DVS20	D20	D25	D40
Direct acting pressure relief valve	•	•	•	•							
Pilot operated pressure relief valve		•		•	•	•	•	•	•	•	•
2 stage pilot operated relief valve		•		•	•	•	•		•	•	•
Externally piloted valve	•	•	•	•	•	•	•		•	•	•
Solenoid dump valve (12 Vdc)	•	•	•	•	•	•	•				
Solenoid dump valve (24 Vdc)	•	•	•	•	•	•	•				
Main anticavitation check valve		•		•	•	•	•	•	•	•	•
Clamping valve		•	•	•							
SPOOL ACTUATION											
Manual control	•	•	•	•	•	•	•	•	•	•	•
Without lever	•	•	•	•	•	•	•	•	•	•	•
90° joystick control		•	•	•	•	•					
Hydraulic control	•	•	•	•	•	•	•	•	•	•	•
Direct electric control (12-24 Vdc)		•		•							
SPOOL RETURN ACTION											
Spring return	•	•	•	•	•	•	•	•	•	•	•
Detent in A - in B - in A/B	•	•	•	•	•	•	•	•	•	•	•
Detent in 4 th position	•	•	•	•	•	•	•	•	•	•	•
Arrangement for dual control	•	•		•	•	•	•		•		
Hydraulic load limit	•	•		•	•	•					
Pneumatic control ON - OFF		•	•	•	•	•	•	•	•		
Proportional pneumatic control		•	•	•	•	•	•	•	•		
Electrical load limit	•	•		•	•	•					
Electrohydraulic control ON-OFF (12-24 Vdc)		•	•	•	•	•	•	•	•		
Electrohydraulic control PROP. (12-24 Vdc)		•	•	•	•	•	•	•	•		
Electropneumatic control (12-24 Vdc)		•	•	•	•	•	•		•		
AUXILIARY VALVES											
Antishock valve	•	•	•	•	•	•	•	•	•	•	•
Anticavitation valve	•	•	•	•	•	•	•	•	•	•	•
Combined valve	•	•	•		•	•	•		•	•	•
Pilot combined valve						•		•	•	•	•



GENERAL INDEX

6	General specifications
	Standard working conditions
-	Fluid options
7	Order example Standard thread
	Tie-rod kit classification
	Painting
9	Dimensions
10	Typical curves Pressure drop (P - T)
	Pressure drop (P - 1) Pressure drop (P - A/B)
	Pressure drop (A/B - T)
	Direct relief valve curve Antishock valve curve
	Combined valve curve
	Anticavitation check valve curve
12	Inlet Section
	Order example Inlet side classification
	Valve identification
	Valve arrangement
4.5	Inlet position and available thread type
15	Working section Order example
	Spool identification
	Spool actuation classification for manual control
	Spool actuation classification for hydraulic control Spool return action classification - Spring load values
	Work section identification
	Compatibility table
22	Auxiliary valves identification Intermediate inlet section
22	Order example
	Intermediate inlet section classification
	Valve identification on intermediate inlet section Valve arrangement on intermediate inlet section
	Inlet position and available thread type
25	Intermediate outlet section
	Order example Intermediate outlet section classification
	Intermediate outlet section classification Inlet position and available thread type
	(for BF intermediate)
	Inlet position and available thread type (for BG intermediate)
27	Outlet section (version 1 outlet)
_,	Order example
27	Outlet section (HPCO version outlet)
	Order example - HPCO version outlet
	Outlet with single tank classification Outlet with two tanks classification
	Carry-over connection (HPCO)
31	D9 Spare parts list
	Gasket kits
35	Installation and maintenance
37	General conditions and patents



GENERAL SPECIFICATIONS

Standard working conditions

Description	Value
Ambient operating temperature range	-40°C / +60°C
Kinematic viscosity range	10 ÷ 300 cSt
Max contamination level	9 (NAS 1638) - 20/18/15 (ISO 4406:1999)
Recommended filtration level	β10 > 75 (ISO 16889:2008)
Internal filter (on electroproportional valves pilot line)	30 μm

All information and diagrams in this catalogue refer to a mineral base oil VG46 at 50° C temperature (32 cSt kinematic viscosity)

Fluid options

Types of fluid (according to ISO 6743/4)	Tempera	Compatible gasket		
Oil and Solutions	min	max	Compatible gasket	
Mineral Oil HL, HM (or HLP acc. to DIN 51524)	-25	+80	NBR	
Oil in water emulsions HFA	+5	+55	NBR	
Water in oil emulsions HFB	+5	+55	NBR	
Polyglycol-based aqueous solution HFC	-10	+60	NBR	

For special applications and different fluids, please call our Technical Department.



ORDER EXAMPLE

D9/1: IR 001 150 A G03 | W001A H004 F001A RP G03 01 PA 100 01 PB 100 | TJ A G04

TYPE:

D9: product type

/1: working section number

1) INLET ARRANGEMENT: (page 12)

IR 001 inlet side and valve type

150 setting (bar)

A G03 inlet position and available thread type

2) WORK SECTION ARRANGEMENT: (page 15)

W001A spool type


H004spool actuation typeF001Aspool return action typeRP G03type and thread section01 PA 100auxiliary valve (port A)01 PB 100auxiliary valve (port B)

3) OUTLET ARRANGEMENT: (page 27)

TJ outlet type

A G04 outlet position and available thread type

Ordering row 2 must be repeated for every work section



Standard thread


The connection ports size is indicated by an ordering code common for all Walvoil products. Following table shows all available connections; for ordering code refer to table on page 36.

Ports	BSP (ISO - 228)	Code	UN-UNF (ISO - 725)	Code
Inlet Port (P)	G 3/8	G03	3/4" - 16 UNF	U03
Ports (A - B)	G 3/8	G03	3/4" - 16 UNF	U03
Outlet (T) - Carry over (HPCO)	G 1/2	G04	7/8" - 14 UNF	U04
Hydraulic Pilot	G 1/4	G02	9/16" - 18 UNF	U02
Pneumatic Pilot	G 1/8	-	NPTF 1/8-27	-



Tie-rod kit classification

Tie rod kit allows the correct assembly of sectional valves. Tie rod's length depends on the number of sections; each valve is assembled with tie rod kits including a tie rod, two nuts and two washers. D9 requires 4 tie-rod kits.



Tie rod kit	Order Code	Lenght (mm)	Clamping Torque (Nm)	Quantity
D9/1	300146001	126		
D9/2	300146002	157		
D9/3	300146003	188		
D9/4	300146004	219		
D9/5	300146005	259		
D9/6	300146006	281	25	4
D9/7	300146007	312	25	4
D9/8	300146008	343		
D9/9	300146009	374		
D9/10	300146010	405		
D9/11	300146011	436		
D9/12	300146012	467		

Painting

On request, all Walvoil valves can be delivered painted (RAL 9005 black primer).

Order example of D9/1 painted:


D9/1 IR 001 150 A G03 W001A H004 F001A RP G03 01 PA 100 01 PB 120 TJ A G04 P006/1 N10

The painting is indicated with the following value:



🖎 walvoil

DIMENSIONS



ТҮРЕ	/1	/2	/3	/4	/5	/6	/7	/8	/9	/10	/11	/12
X (mm)	125	156	187	218	249	280	311	342	373	404	435	466
Y (mm)	137	168	199	230	261	292	323	354	385	416	447	478
Weights (kg)	4,5	6,2	7,9	9,6	11,3	13	14,7	16,4	18,1	19,8	21,5	23,2







TYPICAL CURVES


Indicated values have been tested with standard sectional valve and W001A spool.


Pressure drop (P - T)







Pressure drop (P - A/B)






Pressure drop (A/B - T)





Direct relief valve curve

Setting ranges								
type	pressure (bar)							
А	30 - 110							
В	111 - 220							
С	221 - 350							






TYPICAL CURVES

Indicated values have been tested with standard sectional valve and W001A spool.


Antishock valve curve

Setting ranges								
	pressure (bar)							
type -	at full flow	at min. flow						
Α	20 - 100	10-A / 80-A						
В	101 - 220	81-A / 180-A						
С	221 - 350	181-A / 350-A						




Combined valve curve

Setting ranges								
tuno	pressure (bar)							
type	at full flow	at min. flow						
Α	20 - 60	10-A / 40-A						
В	61 - 100	41-A / 80-A						
С	101 - 220	81-A / 180-A						
D	221 - 350	181-A / 350-A						



Anticavitation check valve curve








INLET SECTION

Order example

			IR	001	150	A G03
	IR	inlet side —				
1.	001	valve arrangement —				
	150	setting (bar)				
2.	A G03	inlet position and available thread type —				




Rif.	Code	Description	Page	
	IR	Sectional valve with right inlet section	12	
_	IL	Sectional valve with left inlet section	13	
	001	Direct acting pressure relief valve		
	004	Direct acting pressure relief valve and Solenoid dump valve 12 Vdc		
1	005	Direct acting pressure relief valve and Solenoid dump valve 24 Vdc		
	019	without valves		
	A G03	Upper inlet (thread G 3/8)	14	
_	A U03	Upper inlet (thread 3/4" - 16 UNF)		
2	E G03	Upper inlet-Outlet (thread G 3/8)		
	E U03	Upper inlet-Outlet (tthread 3/4" - 16 UNF)		

NOTE: when ordering a relief valve it is necessary to specify factory setting (example 150).




Inlet side classifications



Valve identification

type	schema	layout	description	type	schema	layout	description
1	T P		Direct acting pressure relief valve	7		Solenoid dump valve 12 Vdc	
3	T P		Relief valve plugged	8			Solenoid dump valve 24 Vdc
6	XP		Externaly piloted valve	11	РЖ		Plug with pressure-gauge connection

Valve arrangement



Combination valve example: 001 = 1A - 3B

001	Combination valve
1A	Pressure relief valve in port A————
3B	Relief valve plugged in port B

The code identifies:

with a number, the type of valve; with a letter its position on the inlet section.

- (A) = spool action side
- (B) = spool return action side


NOTE: when ordering a main relief valve it is necessary to specify setting





	VALVE COMBINATION		Valve type on port B						
_						O		C	
11	NLET SE	CTION	1	3	6	7	8	11	
		1		001	003	004	005	800	
port A		3	017	019	022	023	024	027	
0		6	046	048				052	
Valve type		7	053	055				059	
Valve		8	060	062				066	
		11	084	086	089	090	091		

Inlet position and available thread type




NOTE: code ${\bf ``E''}$ on inlet section obliges to choice ${\bf ``E''}$ or ${\bf ``W''}$ on outlet section.



WORKING SECTION

Order example:

	W001A	H004	F001A	RP G03	01 PA 100	01 PB 100
1. W001A 2. H004 3. F001A 4. RP G03 5. 01 PA 10 6. 01 PB 10		- handle sid	,			



Rif.	Code	Description	Page
1	W001A	3 positions double-acting	16
1	W002A	3 positions double-acting A-B to tank	
	H001	Protected lever	
2	H004	Control without lever	18
	H006	hydraulic actuation	
_	F001A	3 positions spring-centred spool (spring A)	
3	F002A	3 positions spring-centred spool detent in A and B (spring A)	19
	RP G03	Parallel circuit (G 3/8)	
4	RP U03	Parallel circuit (3/4"-16 UNF)	20
4	RT G03	Parallel-Tandem circuit (G 3/8)	20
	RT U03	Parallel-Tandem circuit (3/4"-16 UNF)	
	01 PA 100	Antishock valve (port A)	
5	05 PA	Prearrangement for auxiliary valve (port A)	
_	01 PB 100	Antishock valve (port B)	21
6	05 PB	Prearrangement for auxiliary valve (port B)	

NOTE: (*) Leave out the spool return action code when choosing H006.

Sections designed to house auxiliary valve option require double choice on work ports A and B.

Always indicate setting value when using antishock and combined valve: 01 PA (100) - 03 PA (100)





Spool identification

order example of spool: **W001** A **J10**

W001	spool schema	3 positions double-acting
Α	spool type	standard spool
J10	restricted service ports	restriction on diameter (0,10 mm in A and B)

W001	3 positions double-acting	T T T T P
W002	3 positions double-acting A and B to tank	T P P
W003	3 positions double-acting A to tank B blocked	T P P
W004	3 positions double-acting A blocked B to tank	T P P
W005	3 positions single - acting on A	O A T
W006	3 positions single - acting on B	B O F P
W012	4 positions double-acting with float in the 4^{th} position	T P
W013	3 positions double-acting regenerative	T T T T P
W015	3 positions double-acting series	B O A
W016	3 positions double-acting series A and B to tank	B O A

	spools with restricted service ports					
code	circuit	restriction on diameter (mm)	section (mm²)	hydraulic schema		
J10	A-B IN T	0,10	1,88	T P		
K10	A IN T	0,10	1,88	T B O A		
Y10	B IN T	0,10	1,88	T P		

D9 SECTIONAL VALVE



	spool type available				
CODE	STANDARD	METERED			
CODL	A	В			
W001	W001A	W001B			
W002	W002A	W002B			
W003	W003A	W003B			
W004	W004A	W004B			
W005	W005A	W005B			
W006	W006A	W006B			
W012	W012A				
W013	W013A				
W015	W015A				
W016	W016A				

NOTE:

- W012, W013, spools need a special machining on the valve body.W015, W016, spools need RS type body.

- Float spool (W012) need special detent kit (F005).
 Regenerative spool (W013) need special return spring kits.
 Different spools are available on request.

Plaese contact our Sales department for more information.





Spool actuation classification for manual control


code	description	dimensions	configuration
H001	Protected lever	N8 N	
H002	Protected lever rotated 180°	63.5	and the second second
Н004	Control without lever	05 00 00 00 00 00 00 00 00 00 00 00 00 0	

Spool actuation classification for Hydraulic control

code	description	dimensions	configuration
H006 leave out the spool return action code	Hydraulic actuation with side ports BSP ports = G 1/4 UNF ports = 9/16-18 UNF	55 254 79	

Hydraulic pilot control curve

The diagram shows the spool stroke as a function of the pressure operating.








Spool return action classification - Springs load values

Spool return kits have three different spring types; following the codes depending on spring loads.


Spring type						
Type - Code A (standard spring) B (soft spring) C (heavy spring)						
Preloading	100 N	80 N	120 N			
End of stroke	150 N	130 N	180 N			
Spool return action identification example						
Type - Code F001A F001B F001C						



code	description	schema	dimensions	configuration
F001A F001B F001C	3 positions spring-centred spool	-WBOA₽	35	
F002A	3 positions spring-centred spool detent in A and B	BA WBOA=		
F003A	3 positions spring-centred spool detent in A	BOA D		
F004A	3 positions spring-centred spool detent in B	B WBOA 0		O Plan
F005A	4 positions spring-centred spool detent in 4 th position (only for W012 spool)		70	
F013A F013B F013C	3 positions spring-centred spool prearrangement dual command	€ WBOA	62.5	




Work section identification




Parallel circuit

When the spool is operated it intercepts the by-pass gallery by diverting the flow of oil to service port A or B. If two or more spools are actuated at the same time, the oil will power the service port that has the lower load; by throttling the spools, the flow of oil can be divided between two or more service ports.



Parallel-Tandem circuit

When the spool is operated it intercepts the switch gallery by diverting the flow of oil to service port A or B. The Tandem circuit is powered by the switch gallery thus permitting the use of just one work section at a time. The section downstream from the tandem section that has been actuated does not operate, the upstream section has priority.



Series circuit

When the spool is operated it intercepts the switch gallery by diverting the flow of oil to service port A or B. The oil that flows back from the actuator is carried to the switch gallery thus making it available to the service ports downstream from the series section. The pressure drop downstream is added to the pressure drop of the section itself.

Compatibility table

								SPOOI	L TYPE							
SPOOL ACTION TYPE	W001A	W001B	W002A	W002B	W003A	W003B	W004A	W004B	W005A	W005B	W006A	W006B	W012A	W013A	W015A	W016A
H001	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H002	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
H004	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Н006	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
SPOOL	SPOOL TYPE															
RETURN ACTION TYPE	W001A	W001B	W002A	W002B	W003A	W003B	W004A	W004B	W005A	W005B	W006A	W006B	W012A	W013A	W015A	W016A
F001	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•
F002	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•
F003	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•
F004	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•
F005													•			
F013	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•





Auxiliary valve identification

code	description	schema	configuration		setting ra	nge (b	ar)
coue	description	Scheilla	Configuration	type	at full flow	type	at min. flow
	Antishock			A	20 / 100	A	10-A / 80-A
01PA	valve	₩Ţ,		В	101 / 220	В	81-A / 180-A
	(port A)			С	221 / 350	С	181-A / 350-A
02PA	Anticavitation valve (port A)	\bigcirc					
		ا <u></u>		A	20 / 60	A	10-A / 40-A
03PA	Combined valve			В	61 / 100	В	41-A / 80-A
USPA	(port A)	:-[<u> </u> _\$]W		С	101 / 220	С	81-A / 180-A
				D	D 221 / 350 D		181-A / 350-A
05PA	Prearrangement for auxiliary valve (port A)	HΗ					

_					setting ra	inge (b	oar)
code	description	schema	configuration	type	at full flow	type	at min. flow
	Antishock			A	20 / 100	A	10-A / 80-A
01PB	valve	W.		В	101 / 220	В	81-A / 180-A
	(port B)			С	221 / 350	С	181-A / 350-A
02РВ	Anticavitation valve (port B)	\bigcirc					
				A	20 / 60	A	10-A / 40-A
0200	Combined	; 		В	61 / 100	В	41-A / 80-A
03PB	valve (port B)	:-[<u> </u> <u>\$</u>]W		С	101 / 220	С	81-A / 180-A
				D	221 / 350	D	181-A / 350-A
05РВ	Prearrangement for auxiliary valve (port B)	ΗH					

Auxiliary valve - Setting range

Sections designed to house auxiliary valve option require double choise on work ports A and B. Always indicate setting value when using antishock valve and combined valve:


01PA (120) = setting at full flow 01PA (120-A) = setting at min. flow



INTERMEDIATE INLET SECTION

Order example

			BE	001	150	A G04
					$\overline{}$	
	BE	inlet side —————————————————————				
1.	009	valve arrangement —				
	150	setting (bar); when ordering a main relief va	lve it is neces	sary to specify	/ setting —	
2.	A G03	inlet position and available thread type ——				




Rif.	Code	Description	Page
-	BE BV*	Intermediate inlet section Intermediate inlet section with pressure relief valve	23
1	001 019	Direct acting pressure relief valve without valves	
2	A G03 A U03	Upper inlet (thread G 3/8) Upper inlet (thread 3/4"-16 UNF)	24

NOTE: when ordering a relief valve it is necessary to specify factory setting (example 150).


^{* =} omit the code for inlet positioning and thread.



Intermediate inlet section classifications



The intermediate inlet section is driven by two pumps (P + P1). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.




The intermediate inlet section and the elements are driven by a single pump (P). The downstream elements can be set to a lower pressure than the upstream ones by adjusting the pressure relief valve of the intermediate section in question.

Valve identification on intermediate inlet section

type	schema	layout	description	type	schema	configurazione	descrizione
1	T P		Direct acting pressure relief valve	11	<u>Р</u>		Plug with pressure-gauge connection
3	T P		Relief valve plugged				

Valve arrangement on intermediate inlet section



Combination valve example: 001 = 1A - 3B

001	Combination valve
1A	Pressure relief valve in port A
3B	Relief valve plugged in port B

The code identifies:

with a number, the type of valve; with a letter its position on the inlet section.

- (A) = spool action side
- (B) = spool return action side

NOTE: when ordering a main relief valve it is necessary to specify setting






	AVAILABLE COMBINATIONS ON INLET SECTION		Valv	e type on po	ort B
C					
			1	3	11
port A	CO	1		001	008
0		3	017	019	027
Valve type	C	11	084	086	

Inlet position and available thread type

	Inlet position and thread available	
A G03	Inlet (P1)	Upper inlet (D1)
A U03		Upper inlet (P1)


Complete configuration samples for D9/2 with intermediate inlet section (BE)

IR 001 150 A G03...... Right inlet section W001A H006 RP G03 Working section BE 001 120 A G03.....Intermediate inlet section W001A H006 RP G03 Working section TJ A G04...... Outlet section



Complete configuration samples for D9/2 with intermediate inlet section (BV)

IR 001 150 A G03..... Right inlet section W001A H006 RP G03 Working section BV 009 120Intermediate inlet section W001A H006 RP G03 Working section TJ A G04......Outlet section






INTERMEDIATE OUTLET SECTION

Order example

BF A G04


BF intermediate outlet type —

1. A G04 outlet position and available thread type -




Rif.	Code	Type	Description	Page
_	BF		Intermediate outlet section with single tank return	25
	BG		Intermediate outlet section with two tank returns	
1	A G04	for BF	Upper outlet (thread G 1/2)	26
_	J G04	for BG	Upper outlet HPCO - front side A and rear side B to T (thread G $1/2$)	

Intermediate outlet section classifications




The above outlet section allows the flow of oil of the two pumps and the tank ports to be piped to a single outlet T.




The section in question allows the flow of oil of the two pumps to be piped in two outlets: HPCO for powering another directional control valve, T for discharge of the work ports. In order to obtain this, the two T need to be linked.



Outlet position and available thread type (for BF intemediate)




Outlet position and available thread type (for BG intemediate)




Complete configuration samples for D9/2 with intermediate outlet section (BF)

IR 001 150 A G03...... Right inlet section W001A H006 RP G03 Working section BF A G04Intermediate outlet section W001A H006 RP G03 Working section IL 001 150 A G03 Left inlet section



Complete configuration samples for D9/2 with intermediate oulet section (BG)


IR 001 150 A G03...... Right inlet section W001A H006 RP G03 Working section BG W G04.....Intermediate outlet section W001A H006 RP G03 Working section IL 001 150 A G03 Left inlet section





OUTLET SECTION (VERSION 1 OUTLET)

Order example






Rif.	Code	Description	Page
-1	TJ	Outlet section with single return (T) right-side inlet (P)	
_	TK	Outlet section with single return (T) left-side inlet (P)	
	A G04	Upper outlet (thread G 1/2)	28
_	A U04	Upper outlet (thread 7/8" - 14 UNF)	
2	E G04	Upper outlet (inlet-outlet) (thread G 1/2)	
	E U04	Upper outlet (inlet-outlet) (thread 7/8" - 14 UNF)	

OUTLET SECTION (HPCO VERSION OUTLET)

Order example - HPCO version Outlet




			TM	W G04	
1.	тм	outlet section typ	oe		
2	W G04	outlet position an	d available t	hread tyne	

Rif.	Code	Description	Page
1	TM TN	Outlet section with two return (T-HPCO) right-side inlet (P) Outlet section with two return (T-HPCO) left-side inlet (P)	29
2	W G04	HPCO upper inlet outlet - T (tank) upper outlet section (thread G 1/2)	





Outlet with single tank classification




Outlet position

	outlet combination and thread available	
A G04	Outlet (T) Inlet (P)	Upper outlet (thread G 1/2)
A U04		Upper outlet (thread 7/8" - 14 UNF)
E G04	Inlet (P) Outlet (T)	Upper outlet (inlet - outlet) (thread G 1/2)
E U04		Upper outlet (inlet - outlet) (thread 7/8" - 14 UNF)


NOTE: code "E" on outlet section obliges to choice "E" on inlet section.



Outlet with two tanks classification



Outlet position




NOTE: code "W" on outlet section obliges to choice "E" on inlet section.






Carry-over connection (HPCO)

This option, available on all D9, allows the sectional valve to feed a second valve, by extending the free flow channel. In this configuration, the valve need a separated port for connection to tank.




It is possible to transform sectional valve from standard to HPCO version just by ordering the appropriate conic plug:



code (HPCO Plug identification)	description	q.ty
413010203	conic plug G 1/4 x 13	1



D9 SPARE PARTS LIST



Ref.	Description	Order code	Q.ty	Code	Note
		84642			Setting: 100 bar
	Direct acting pressure relief valve (*)	29005	1		Setting: 200 bar
		38339			Setting: 300 bar
	Relief valve plugged	430146001	1		
1	External piloted valve	915044604	1	-	
	Solenoid dump valve (12 vdc) (**)	915044601	1		
	Solenoid dump valve (24 vdc) (**)	915044602	1		
	Plug with pressure-gauge connection	430146002	1		
		421246059		W001A	_
	3 positions double-acting spool	421246055		W001B	_
	3 positions double-acting A and B to tank spool	421246060	_	W002A	_
2	3 positions single-acting on A	421246005	- 1	W005A	_
	3 positions single-acting on B	421246064		W006A	_
	4 positions double-acting with float in the 4 th pos.	421246065	_	W012A	_
	0 1 117	422501119			only for protected lever
3	Spool end kit	422501132	- 1		only for control without lever
		320346001			
	Protected lever	320346002	- 1	H001 = H002	only for W012 spool
	Comband with such laws	320346003		11004	
4	Control without lever	320346004	- 1	H004	only for W012 spool
		320546001	2		BSP ports
	Hydraulic actuation with side ports	320546035	2	H006	UNF ports
		320546004	2		BSP ports for W012 spool
	3 position spring centres spool	320746002	_	F001A	
	Detent in A and B	320846001	_	F002A	
5	Detent in A	320846002	- 1	F003A	
	Detent in B	320846003	_ •	F004A	
	Detent in 4 th position	320846004	_	F005A	only for W012 spool
	Prearrangement dual command	320746005		F013A	





Ref.	Description	Order code	Q.ty	Code	Note
6	Check valve on the work section	320246001	1	-	only for RP and RT section
		915063027			Setting: 100 bar
	Antishock valve on port A	915063026		01 PA	Setting: 200 bar
		915063025			Setting: 300 bar
7	Anticavitation valve on port A	915083001		02 PA	
,		23504	1		Setting: 100 bar
	Combined valve on port A	14779		03 PA	Setting: 200 bar
		38346			Setting: 300 bar
	Prearrangement for auxiliary valve on port A	430404001		05 PA	
		915063027			Setting: 100 bar
	Antishock valve on port B	915063026		01 PB	Setting: 200 bar
		915063025			Setting: 300 bar
8	Anticavitation valve on port B	915080401	1	02 PB	
0		23504	1		Setting: 100 bar
	Combined valve on port B	14779		03 PB	Setting: 200 bar
		38346			Setting: 300 bar
	Prearrangement for auxiliary valve on port B	430404001		05 PB	
	Plug kit (G 3/8)	430000018		G03	
9	Plug kit (G 1/2)	kit (G 1/2) 430000019		G04	
9	Plug kit (3/4"-16 UNF)	300001006	1 _	U03	
	Plug kit (7/8"-14 UNF)	300004003		U04	


D9 SECTIONAL VALVE



Note

(*) = for different settings please contact our Sales Dpt.


(**) = electric dump valve coil can be ordered separately as spare part: (see drawing "A") Ordering code Coil 12 vdc: **413171235** Ordering code Coil 24 vdc: 413172432







Gasket kit



INLET AND WORK SECTION						
Rif.	ORDER CODE	DESCRIPTION	Q.ty			
1	412010634	O.R. 70SH 50,47 x 2,62 (2-136)	1			
	Complete Ga	sket kit: order code - 350946001				





INSTALLATION AND MAINTENANCE

Guidelines


- Mount the control valve securely to a flat surface (recommended 3 point fixing); at the time do not use a hammer to positioning by hitting.
- When handling the control valve, be careful not hold the pilot cover or return spring cap of the spool or accessory valves such as main relief valves and anti-shock relief valves.
- Clean piping materials sufficiently before use.
- Make sure to prevent the port openings from being entered with dust or foreign matters.
- Tighten the port connectors surely with the recommended fastening torques.
- Do not direct the jet of a pressure washing unit directly to the valve.

Fittings tightening torque (Nm)

thread type	port P	Port A - B	Port T
BSP (ISO - 228)	G 3/8	G 3/8	G 3/8
with rubber sealing (DIN 3869)	40	40	40
with copper or steel and rubber washer	40	40	40
BSP (ISO - 228)	G 1/2	G 1/2	G 1/2
with rubber sealing (DIN 3869)	70	70	70
with copper or steel and rubber washer	70	70	70
UN-UNF (ISO - 725)	3/4" - 16 UNF	3/4" - 16 UNF	3/4" - 16 UNF
with O.R.	40	40	40
UN-UNF (ISO - 725)	7/8" - 14 UNF	7/8" - 14 UNF	7/8" - 14 UNF
with O.R.	90	90	90

General clamping torque

The following table provides the main tightening torques of the distributor D9:







Dimensions - Thread codes


The connection ports size is indicated by an ordering code common for all Walvoil products. Following table shows all available connections.

METRIC T	HREAD (ISC	9974-1)		
Type	M18x1,5	M22x1,5	M27x2	
Code	M01	M02	M03	

BSP THRE	AD (ISO 11	79-1)						
Туре	1/4"	3/8"	1/2"	3/4"	1"	1″1/4	1″1/2	2"
Code	G02	G03	G04	G05	G06	G07	G08	G09

UN / UNF THREAD (ISO 11926-1)								
Туре	9/16" 18 UNF	3/4" 16 UNF	7/8" 14 UNF	1"1/16 12 UNF	1"5/16 12 UNF	1"5/8 12 UNF		
1,700	SAE6	SAE8	SAE10	SAE12	SAE16	SAE20		
Code	U02	U03	U04	U05	U06	U07		

Dimensions - SAE Flange codes



SAE / 3000 FLANGE (ISO 6162-1)												
Type	3/4" (MA)	3/4" (UNC)	1" (MA)	1" (UNC)	1″1/4 (MA)	1"1/4 (UNC)	1″1/2 (MA)	1″1/2 (UNC)	2" (MA)	2" (UNC)	3" (MA)	3" (UNC)
Code	S03	S04	S05	S06	S07	S08	S09	S10	S11	S12	S15	S16
Α	19	19	25	25	32	32	38	38	51	51	76	76
В	47,6	47,6	52,4	52,4	58,7	58,7	69,9	69,9	77,8	77,8	106,4	106,4
С	22,3	22,3	26,2	26,2	30,2	30,2	35,7	35,7	42,9	42,9	61,9	61,9
D	M10	3/8-16	M10	3/8-16	M10	7/16-14	M12	1/2-13	M12	1/2-13	M16	5/8-11

SAE / 6	SAE / 6000 FLANGE (ISO 6162-2)							
Type	3/4"	3/4"	1"	1"	1″1/4	1″1/4	1″1/2	1″1/2
.,,,,	(MA)	(UNC)	(MA)	(UNC)	(MA)	(UNC)	(MA)	(UNC)
Code	S33	S34	S35	S36	S37	S38	S39	S40
Α	19	19	25	25	32	32	38	38
В	50,8	50,8	57,2	57,2	66,6	66,6	79,3	79,3
С	23,8	23,8	27,8	27,8	31,8	31,8	36,5	36,5
D	M10	3/8-16	M12	7/16-14	M14	1/2-13	M16	5/8-11



GENERAL CONDITIONS AND PATENTS

Introduction

These general conditions apply to all general supplies from Walvoil s.p.a., after receiving orders from the Customer. Should commercial terms such as EXW, DDP, etc be mentioned, of course the Incoterms of the International Chamber of Commerce must be referred to, according to the test existing when the general supply conditions are agreed on.

Management of orders

No Customer's order is binding to Walvoil s.p.a. if Walvoil s.p.a. has not confirmed the order in writing. Walvoil s.p.a. commits to supplying the orders in compliance with the order confirmation that has been issued. Any disagreement with the content of the order confirmation must be communicated in writing to Walvoil s.p.a. within and no later than 5 days from the delivery of the order confirmation. The Customer commits to paying for the goods supplied by Walvoil s.p.a., according to the prices indicated on the order confirmation.

Payment conditions

The Parties agree on the payment terms at the beginning of the supply. The terms will be indicated on the order confirmation. Should the Customer be late with the payments, Walvoil S.p.a. will be entitled to require the payment of interests on arrears based on the exiting Prime Rate increased by 2%. Should there be any payment delay, Walvoil s.p.a. will be entitled not to process the Customer's purchase order, even if it has already been confirmed.

Delivery and shipment

The goods are always supplied Ex Works, even when Walvoil s.p.a. agrees with the Customer that the shipment, or a part of it, will be arranged by Walvoil s.p.a. It is agreed that the Customer will bear the risk of goods deterioration or damaging from the moment the goods are handed by Walvoil s.p.a. to the first carrier.

Product characteristics

Walvoil s.p.a. commits to supplying good quality products, compliant with the technical specifications declared on the technical tables and on the catalogue. Walvoil s.p.a, even without notice, at its own discretion, reserves the right to modify the products as necessary, without these changes altering the main characteristics of the products.

Claims

Any claims about defects on delivered products (just as an example: claims about the packaging, the number, the quantity or the external product characteristics) will have to be notified to Walvoil s.p.a. in writing, within and no later than 7 days from reception of the goods, otherwise the claims will be considered as null and void. Occult defects (the defects of the goods that cannot be spotted with a careful control of the goods received by the Customer), will have to be notified in writing to Walvoil s.p.a. within 7 days from the discovery of the defect, and anyhow no later than 12 months from the delivery of the goods, otherwise the claim will be considered as null and void. Even in case of claim or objection, the Customer will never be entitled to suspend or delay the payments to Walvoil s.p.a. for the products subject to claim or objection nor for any other supply.



GENERAL CONDITIONS AND PATENTS

Warranty

Should the products supplied by Walvoil not be compliant or have the required quality and should this defect be due to Walvoil, Walvoil s.p.a. commits, at its choice, to replace or repair the faulty products, as long as the defect or lack of compliance is notified to Walvoil s.p.a. in writing, as specified at point 6, within and no later than 18 months from product delivery. On the products that have been fixed or replaced in accordance with what specified above, the above-mentioned warranty applies. The 12 month duration starts from the date of repair or replacement. In case of defects, lack of quality or in case of lack of compliance for the supplied products, with the exception of fraud or serious offence, Walvoil s.p.a. only commits to repairing or replacing the faulty products, according to what specified above. This warranty replaces any other Supplier's warranty or liability established by the law. This warranty excludes any other liability contractual or extra-contractual by Walvoil s.p.a. on the products supplied by Walvoil (as a mere example: damage refund, loss of profit, product recall campaign, etc). Walvoil s.p.a. has signed a product civil liability police, with a suitable maximum coverage.

Ownership retention

The products supplied by Walvoil s.p.a. will be owned by the latter until Walvoil receives the complete payment for the supplied goods.

Obligation confidentiality

Walvoil s.p.a. commits to not disclosing the technical and commercial information it receives from the Customer, unless this information has already been publicly disclosed.

Patents

The Customer is not allowed to use the provided Products, or a part of them, their descriptions or drawings protected or not protected by Patent or registered trademark in order to design or make similar products, unless Walvoil s.p.a. previously issues its written authorization. Should Walvoil s.p.a. give its written authorization, all patents, trademarks, registered designs, copyrights and intellectual property rights related or connected to the Products provided by Walvoil s.p.a. will stay Walvoil's property. The Customer commits to respecting the highest confidentiality.

Applicable law and court of jurisdiction

Walvoil s.p.a.'s supplies are regulated by these General Supply Conditions and, for anything not defined here, by the Italian law. Any controversy related, generated or connected to the supply of Products by Walvoil s.p.a., where Walvoil s.p.a. is involved, will be exclusively dealt with by the Court of Bologna.

Walvoil worldwide

WALVOIL S.P.A.

DIREZIONE E COORDINAMENTO INTERPUMP GROUP S.P.A. Headquarters, Subsidiaries and Representative Offices

Walvoil S.p.A. Headquarters

Via Adige, 13/D . 42124 Reggio Emilia . Italy TEL. +39 0522 932411 info@walvoil.com | www.walvoil.com

AUSTRALASIA

Walvoil Fluid Power Australasia Pty Ltd

13 Vanessa Way . Delahey VIC 3037 . Melbourne . Australia TEL. +61 458 918 750 australasia@walvoil.com

BRAZIL

Interpump Hydraulics Brasil Ltda | Walvoil Division

Rua Gilberto de Zorzi, 525 . Bairro Forqueta 95115-730 Caxias do Sul (RS) TEL. +55 54 3289 7000 infobrasil@walvoil.com

CANADA

Walvoil Canada Inc.

3100, Rue Jacob Jordan . Terrebonne . Qc J6X 4J6 . Canada TEL. +1 450 477 1076 Ext:225 info@walvoilcanada.com | www.walvoilcanada.com

CHINA

Walvoil Fluid Power (Dongguan) Co. Ltd

1st Floor, the Third Factory Area, Sijia, Shijie Town, Dongguan City Guangdong province. China. TEL. +86 769 81816189-8020 info@walvoil.com.cn | www.walvoil.com.cn

SOUTH KOREA

Walvoil Fluid Power Korea Ltd.

(17818)80-15, Oseongsandan 1Ro, Oseong-myun, Pyeongtaek-si Gyeonggi-do Republic of Korea 451-872 TEL. +82 31 682 6030 info@walvoil.co.kr | www.walvoil.co.kr

FRANCE

Walvoil Fluid Power France

362 rue de Bretagne . Vritz . 44540 Vallons-de-l'Erdre TEL. +33 2 41 94 41 06 france@walvoil.com

INDIA

Walvoil Fluid Power (India) PVT. LTD.

No. 1, 2nd Cross, 2nd Main, KIADB Industrial Area, Attibele, Anekal Taluk Bangalore - 562107 . TEL. +91 80 0614 24000 info@walvoil.co.in | www.walvoil.co.in

U.S.A.

Walvoil Fluid Power Corp.

4111 North Garnett Tulsa, OK 74116, USA TEL. +1 918 858 7100 info@walvoilusa.com | www.walvoilusa.com

Walvoil Fluid Power Corp | Hydrocontrol Business Unit

1109, Technology Drive . Red Wing . MN 55066 . U.S.A. TEL. +1 651 212 6400 info@walvoilusa.com | www.walvoilusa.com

3rd edition Jan.2024 www.walvoil.com



